


K82 RGB BACKLIGHT MECHANICAL KEYBOARD

简体中文



键盘参数

按键寿命: 5000万次
使用最大电流: 500mA
重量: 617g±20g(不带线)

工作电压:DC5V±5%
尺寸: 350x134x37mm

技术特点

1. RGB酷炫LED灯光特效
2. 悬浮式键帽设计
3. 全键盘无冲突, 快速响应
4. 1680万种颜色, 可自定义偏暗色彩
5. 全机械开关, 职业电竞玩家标配装备
6. 多媒体功能组合键, 工作游戏兼顾
7. 免EEPROM记忆, 芯片采用Flash记忆

- 1 -

功能说明:

1. 支持常用游戏模式按键背光及自定义录制按键背光功能。
2. 支持14种酷炫LED灯光特效, 按FN+ [] 切换灯光顺序繁星点点, 随按随灭, 混光模式, 游戏高手, 川流不息, 随按随亮, 正弦光波, 常亮模式, 呼吸模式, 七彩霓虹, 一触即发, 雨滴滑落, 彩虹转盘, 涟漪扩散。
3. 支持FN+ [] 五级速度调节, 支持FN+ [] 个别模式下方向调节, 支持FN+ [] 五级亮度调节。
4. 支持全键无冲。
5. 支持Lock [] 功能, 同时锁住 [] 和 [] 键。
6. 支持FN+ [] 复位功能, 恢复到“繁星点点”默认灯光设置。
7. 支持FN+ [] 关/开背光功能。

灯光特效模式切换顺序
键盘插入电脑USB上电开机, 展开跑马灯动画, 然后进入用户在最后一次使用的功能及灯光模式状态。

- 按FN+[] 进入“繁星点点”：
 - 键盘的背光如夜空之点点繁星, 五光十色, 眨眼闪烁。
 - 通过 FN+[] 闪烁速度和数量可按用户喜好调节。
- 支持 FN+[] 五级速度调节, FN+[] 五级亮度调节
- 再次按下FN+[] 进入“随按随亮”：
 - 键盘整体背光亮亮, 亮度/颜色之前调节的记忆参数为准。
 - 通过 FN+[] 切换随机七彩和7单色, 共8种颜色可调。
- 支持FN+[] 五级速度调节, FN+[] 五级亮度调节。
- 再次按下FN+[] 进入“混光模式”：
 - 键盘背光每排一种颜色, 像彩带一般。
 - 通过 FN+[] 呼吸和常亮调节
- 支持 FN+[] 五级速度调节, FN+[] 五级亮度调节
- 再次按下FN+[] 进入“游戏高手”：
 - 默认设定五组常用游戏按键灯光, 按FN+[] 可进行切换, 也可以任意模式下。

- 2 -

直接按FN+[] 进入相应背光状态。

- FN+[] 均可按FN+[] 可进行自定义录制, 定义按键背光颜色。
- 先按FN+[] 其中任意一个按键后, 再按FN+[] 进入录制模式, 可任意按下按键, 七种颜色循环切换, 直到自己喜欢的颜色。
- 最后按下FN+[] 保存, 录制成功。
- 清除自定义灯光, 先按FN+[] 其中任意一个当前设定的灯光值后, 按下FN+[], 再次按下FN+[] 即可清除成功。
- 再次按下FN+[] 进入“川流不息”：
 - 键盘的背光由右至左或由左至右流动, 呈7彩霓虹。
 - 支持FN+[] 组合键, 可调光波流动的左右方向。
- 支持FN+[] 五级速度调节, FN+[] 五级亮度调节。
- 再次按下FN+[] 进入“随按随亮”：
 - 背光关闭, 默认情况下, 每次按键按下时随即亮起一种背光颜色, 松开按键后按键的背光随之延时熄灭, 7彩随机。
 - 按FN+[] 组合键, 切换随机七彩和7单色, 共8种颜色可调。
- 支持FN+[] 五级速度调节, FN+[] 五级亮度调节。
- 再次按下FN+[] 进入“正弦光波”：
 - 键盘背景为LED关闭状态, 一条七彩光波以正弦曲线形式上下波动翻飞, 拖尾渐灭, 速度越快, 拖尾越长。
 - 按FN+[] 组合键, 切换随机七彩和7单色, 共8种颜色可调。
- 支持FN+[] 五级速度调节, FN+[] 五级亮度调节。
- 再次按下FN+[] 进入“常亮模式”：
 - 键盘整体背光亮亮, 亮度之前调节的记忆参数为准, 七彩色可调。
- 支持FN+[] 组合键, 切换随机七彩和7单色, 共8种颜色可调。
- 支持FN+[] 五级速度调节, FN+[] 五级亮度调节。
- 再次按下FN+[] 进入“呼吸模式”：
 - 键盘整体背光模拟呼吸节奏, 实现由灭至最高亮度的曲线变化, 亮度、颜色及呼吸节奏速度, 以之前调节的记忆参数为准。
- 按FN+[] 组合键, 切换随机七彩和7单色, 共8种颜色可调。
- 支持FN+[] 五级速度调节, FN+[] 五级亮度调节。

- 3 -

●再次按下FN+[] 进入“七彩霓虹”：

- 键盘整体背光亮度不变, 灯光颜色呈七彩逐色交替变幻, 亮度及变幻速度, 以之前调节的记忆参数为准。
- 支持FN+[] 五级速度调节, FN+[] 五级亮度调节。
- 再次按下FN+[] 进入“一触即发”：
 - 背光关闭, 默认情况下, 每次按键按下时, 该行按键亮起一种背光颜色, 向两侧以拖尾方式射出。
 - 按FN+[] 组合键, 切换随机七彩和7单色, 共8种颜色可调。
- 支持FN+[] 五级速度调节, FN+[] 五级亮度调节。
- 再次按下FN+[] 进入“雨滴滑落”：
 - 键盘的背光亮如雨滴贴窗滑落, 五彩斑斓, 时疾时徐。
 - 按FN+[] 组合键, 切换随机七彩和7单色, 共8种颜色可调。
- 支持FN+[] 五级速度调节, FN+[] 五级亮度调节。
- 再次按下FN+[] 进入“彩虹转盘”：
 - 键盘背光颜色状如彩虹转盘旋转, 逐色交替变幻。
 - 支持FN+[] 五级速度调节, FN+[] 五级亮度调节。
- 支持FN+[] 可调光波流动的左右方向。
- 再次按下FN+[] 进入“涟漪扩散”：
 - 以按下的按键为中心, 向四周波动扩散出一层五颜六色波浪, 层层涌动, 渐行渐远。
 - 按FN+[] 组合键, 切换随机七彩和7单色, 共8种颜色可调。
- 支持FN+[] 五级速度调节, FN+[] 五级亮度调节。

- 4 -

游戏高手模式及按键自定义设置

FN+[] A,S,D,W,I,L,←,→,ESC 亮
FN+[] A,S,D,W,Left Ctrl, Left Shift, Alt,Space,R,G,Q,E,B,1-5,Tab,F1-F3,FM,END, P,U,PD,PS 亮
FN+[] Q,W,E,R,T,A,S,D,F,G,C,V,1-7, Left Ctrl, Left Shift 亮
FN+[] Q,W,E,R,A,S,D,F,1-7 亮
FN+[] W,R,A,S,D, Left Ctrl, Left Alt, Left Shift,I,L,←,→ 亮
以上游戏高手灯光模式可在任意功能模式下, 直接按组合键进入。

自定义按键灯光模式设置方法:


FN+[] = 录制键/存储键
FN+[] 均可按FN+[] 可进行自定义录制, 定义按键背光颜色。
先按FN+[] 其中任意一个按键后, 再按FN+[] 进入录制模式, 可任意按下按键, 七种颜色循环切换, 直到自己喜欢的颜色。
最后按下FN+[] 保存, 录制成功。
清除自定义灯光, 先按FN+[] 其中任意一个当前设定的灯光值后, 再按FN+[], 再次按下FN+[] 即可清除成功。

其他组合键功能定义:

FN+[] CD	FN+[] 音量减
FN+[] 音量加	FN+[] 静音
FN+[] 上一曲	FN+[] 暂停/播放
FN+[] 下一曲	FN+[] 停止
FN+[] E-mail	FN+[] 浏览器
FN+[] 我的电脑	FN+[] 计算器

- 5 -

English



Keyboard parameters

Key life: 50 million
Current: 500mA
Weight: 617g±20g (Without line)

Working Voltage:DC5V±5%
Dimension: 350x134x37mm

Technical Features

1. RGB cool LED backlight
2. Suspension keycap design
3. Full keyboard without conflict, fast response
4. 16.8 million kinds of color, color edit customizable
5. All mechanical switches, professional e-sports players standard equipment.
6. Multimedia function key combination, work game balance
7. Free of EEPROM memory, adopt Flash memory chip

- 6 -

Functional specifications

1. Support common game mode key backlight and custom recording key backlight.
2. Support 14 kinds cool LED backlight. FN+[] switch backlight sequence. Starry Sky, Press and off, Mixed light mode, Game master, Never-ending, Press and on, Sinusoidal light wave, Normally on mode, Breathing mode, Colorful neon, Touch and go, Raindrops, Rainbow roulette, Ripples spread.
3. Support FN+[] 5 speed adjustment, support FN+[] direction adjustment under some mode, support FN+[] 5 brightness adjustment.
4. Support full key without conflict.
5. Support Lock [] function, lock [] and [] key.
6. Support FN+[] reset function, restore to "Starry Sky" the default light setting.
7. Support FN+[] off/on backlight function.

Lighting effects model switchover sequence

Plug USB turn on the keyboard, entertaining diversions animation, then enter in last timefunction and light mode of user.

- Press FN+[] into "Starry Sky"：
 - Keyboard backlight looks like starry starry night, multicoloured and blink.
 - Via FN+[] Blink speed and quantity can adjusted according to user preferences.
- Support FN+[] 5 speed adjustment, FN+[] 5 brightness adjustment.
- Press again FN+[] into "Press and Off"：
 - The whole keyboard backlight normally on, brightness/color memory as before.
- Support FN+[] 5 speed adjustment, FN+[] 5 brightness adjustment.
- Press again FN+[] into "Mixed light mode"：
 - Keyboard backlight color every row difference, like a ribbon
 - Via FN+[] breathe and normally on adjustment
- Support FN+[] 5 speed adjustment, FN+[] 5 brightness adjustment.

- 7 -

● Press again FN+[] into "Game master"：

- Default setting 5 groups common used game key light, press FN+[] can switchable. Also can press directly under any mode.
- FN+[] into corresponding backlighting mode.
- FN+[] All can press FN+[] can be customized recording, setting key backlight color.
- After press FN+[] any of a button first, then press FN+[] start recording mode, press any of a button, 7 colors switching, until the favorite color, and press FN+[] save it. recording success.
- Remove custom lighting, press FN+[] any of a current setting light value first, then press FN+[], press again FN+[], remove success.
- Press again FN+[] start "Never-ending"：
 - Keyboard backlight from right to left or from left to right flow, with colorful light.
- Support FN+[] combination key, adjustable optical flow direction
- Support FN+[] 5 speed adjustment, FN+[] brightness adjustment.
- Press again FN+[] start "Press and on"：
 - Light-off, by default, every keystroke press lights up a backlight color, backlight delay outwhile your finger move, 7 colors random.
- Press FN+[] combination key, switching random colorful light and seven colors, total 8 colors adjustable.
- Support FN+[] 5 speed adjustment, FN+[] brightness adjustment.
- Press again FN+[] start "Sinusoidal light wave"：
 - Keyboard LED inactive state, a colorful light in the form of sine curve fluctuates up and down, trailing off gradually. The faster the speed, the longer tail.
- Press FN+[] combination key, switching random colorful light and seven colors, total 8 colors adjustable.
- Support FN+[] 5 speed adjustment, FN+[] brightness adjustment.
- Press again FN+[] start "Normally on mode"：
 - The whole keyboard backlight normally on, brightness memory as before.
- 7 colors adjustable.

- 8 -

- Press FN+[] combination key, switching random colorful light and seven colors, total 8 colors adjustable.

- Support FN+[] 5 brightness adjustment.
- Press again FN+[] to start "Breathing mode"：
 - The whole keyboard backlight simulate breathing rhythm, show curve changes from destroy to the highest brightness. Brightness, color and breath.
 - Rhythm Speed, according to the the parameters of the memory before.
- Press FN+[] combination key, switching random colorful light and seven colors, total 8 colors adjustable.
- Support FN+[] 5 speed adjustment, FN+[] 5 brightness adjustment.
- Press again FN+[] to start "Colorful neon"：
 - The whole keyboard backlight brightness no changes, light color is colorful color fluctuates, brightness and change speed, according to the parameters of the memory before.
- Support FN+[] 5 speed adjustment, FN+[] 5 brightness adjustment.
- Press again FN+[] to start "Touch and go"：
 - Light-off, by default, every time press a key, this row lights up a backlight color, shoot intrailing manner from both sides.
- Press FN+[] combination key, switching random colorful light and seven colors, total 8 colors adjustable.
- Support FN+[] 5 speed adjustment, FN+[] 5 brightness adjustment.
- Press again FN+[] to start "Raindrops"：
 - Keyboard backlight like raindrops stick slip window, particoloured, sometimes fast, sometimes slow.
- Press FN+[] combination key, switching random colorful light and seven colors, total 8 colors adjustable.
- Support FN+[] 5 speed adjustment, FN+[] 5 brightness adjustment.

- 9 -

● Press again FN+[] to start "Rainbow roulette"：

- Keyboard backlight color like colorful wheel spins, color fluctuates.
- Support FN+[] 5 speed adjustment.
- Support FN+[] adjustable optical flow direction.
- Press again FN+[] to start "Ripples spread"：
 - Centered on the pressed button, volatility spread a layer colorful wave, sparkling and fade away.
- Press FN+[] combination key, switching random colorful light and seven colors, total 8 colors adjustable.
- Support FN+[] 5 speed adjustment, FN+[] 5 brightness adjustment.

Game superior mode and key custom setting

FN+[] A,S,D,W,I,L,←,→,ESC (light)
FN+[] A,S,D,W,Left Ctrl, Left Shift, Left Alt,Space,R,G,Q,E,B,1-5,Tab,F1-F3,FM,END, P,U,PD,PS (light)
FN+[] Q,W,E,R,T,A,S,D,F,G,C,V,1-7, Left Ctrl, Left Shift (light)
FN+[] Q,W,E,R,A,S,D,F,1-7 (light)
FN+[] W,R,A,S,D, Left Ctrl, Left Alt, Left Shift,I,L,←,→ (light)

Custom button lights mode setting method:

FN+[] = Recording/store key
FN+[] All can press FN+[] can be customized recording, setting key backlight color. After press FN+[] any of a button first, then press FN+[] start recording mode, press any of a button, 7 colors switching, until the favorite color, and press FN+[] save it. recording success.
Remove custom lighting, press FN+[] any of a current setting light value first, then press FN+[], press again FN+[], remove success.

- 10 -

Other combination key function definition

FN+[] CD	FN+[] Volume reduce
FN+[] Volume increase	FN+[] Mute
FN+[] Prev Track	FN+[] Pause/Play
FN+[] Next Track	FN+[] Stop
FN+[] E-mail	FN+[] Internet
FN+[] My computer	FN+[] Calculator



摩托豹官方旗舰店 MOTOSPEED

运营商：香港飞翔科技集团有限公司
制造商：深圳市宝安区智源电子厂 地址：深圳市宝安区5区前进路
Operator: Motospeed Technology Group Limited
Manufacturer: Mototech Technology Group Limited
Address: Qianjin Road, 5th District, Bao'an Shenzhen Pr. China
HOTLINE: 4008-860-368
以上数据仅供参考, 实物与图片可能不相符!
最终解释权归本公司所有
WWW.MOTOSPEED.CN
WWW.MOTOSPEED.CC

160x118mm